
















## Vehicle Identification/Recognition



## Accessing Vehicle




 Supplemental Restraint System Control Module (SRSCM)	 Airbag	 Airbag Gas Inflators
 High voltage cable	 12V Battery	 Air-conditioning line
 High Voltage Disconnect	 OBC (On – Board Charger)	 Ultra-High Strength Steel
 Low Voltage Disconnect for High Voltage	 Air-conditioning component	 Seat belt pretensioner
 High Voltage Battery		

## Disabling Vehicle



OR



OR



## Vehicle Towing Information

*Tow the vehicle using a flat bed or using wheel dollies. Never tow the vehicle with the front or rear wheels on the ground*



For further information, please refer to the Emergency Response Guide (ERG).